(1/8")
DRILL 3.2 mm HOLE
(2PLACES)

20

265
278

25

290 278 258

Ø12.2

16

24.5

17.6

1. Place the template against the header.

2. Prepare cutout and drill 2 screws holes as per template.

3. Remove the template.

4. Run wires through the loop.

5. Fasten the housing on the header.

6. Fasten one end of the door loop in the housing with 2 screws.

7. Fasten another side of door loop on the door side with 2 screws.

WG-DL260 / 2008 -12